

エラー内容：耐力条件が登録されていないため、金物耐力が取得できませんでした。

【梁接合部】

耐力条件が登録されていないため、金物耐力が取得できませんでした。（金物名称）

⇒ 「金物マスター→横架材端部金物→耐力タブ」において
金物耐力を1つも設定していない時に表示されます。
金物耐力を新規設定してください。

The image shows four screenshots of a software interface for setting bolt master data and beam end joint data.

1. **金物マスター編集** (Bolt Master Edit) window: Shows a list of bolt types. The **小断面** (Small Section) tab is selected. The list includes: HSS, NE_HSS_230331, NE_SSマルチ_230331, NE_テックワンP3_230331 (highlighted), NE_プレセッターSU・TS金物_230331, NE_プレセッタータイプM・TS金物_230331, and NE_プレセッター・TS金物_230331. Buttons for Edit, Add, Delete, Copy, Rename, Import, and Export are visible.

2. **NE_テックワンP3_230331 金物編集** (NE Tech One P3_230331 Bolt Edit) window: Shows the selected bolt type **NE_テックワンP3_230331**. The **横架材端部** (Beam End Joint) tab is selected. The list includes: 柱端部 (Column End), ボルト (Bolt), 座金 (Washer), ナット (Nut), and ドリフトピン (Drift Pin). Buttons for Edit, Add, Delete, Copy, Rename, Import, and Export are visible.

3. **横架材端部金物一覧** (Beam End Joint Bolt List) window: Shows a list of beam end joint bolt types. The list includes: TH-10, TH-10D, TH-10H, TH-10U, TH-18, TH-18D, TH-24, TH-24D, TH-33, TH-33D, TH-45, TH-45D, TH-51D, TH-57, TH-57D, TH-66, and TH-66D. Buttons for Edit and Add are visible.

4. **横架材端部金物編集** (Beam End Joint Bolt Edit) window: Shows the selected bolt type **TH-10**. The **耐力** (Strength) tab is selected. The table shows the strength conditions for the selected bolt type. The table has columns: 条件 (Condition), 長期せん断 (Long-term Shear), 短期せん断 (Short-term Shear), 短期強軸 (Short-term Strong Axis), 逆せん断 (Reverse Shear), and 引張 (Tension). The table is empty, indicating that no strength conditions are registered.