

エラー内容：接合部形式が登録されていないため、金物耐力が取得できませんでした。

【梁接合部】

接合部形式が登録されていないため、金物耐力が取得できませんでした。（金物名称）

⇒「金物マスター→横架材端部金物→耐力タブ」において
金物耐力の登録パターンが不足している時に表示されます。
全ての条件で登録されているか確認してください。

The image shows four screenshots of a software interface for managing joint types and material properties.

金物マスター編集 (Joint Master Edit): A window with a list of joint types. The '小断面' (Small Section) tab is selected. The list includes: HSS, NE_HSS_230331, NE_SSマルチ_230331, NE_テックワンP3_230331 (highlighted), NE_プレセッターSU・TS金物_230331, NE_プレセッタータイプM・TS金物_230331, and NE_プレセッター・TS金物_230331. Buttons for '編集(E)...', '追加(A)...', '削除(D)', 'コピー(C)...', '名称変更(R)...', 'インポート(I)...', and 'エクスポート(F)...' are on the right.

NE_テックワンP3_230331 金物編集 (NE Tech One P3_230331 Joint Edit): A window for editing a specific joint type. The '横架材端部' (End of Transverse Member) tab is selected. The list includes: 柱端部, ボルト, 座金, ナット, and ドリフトピン. Buttons for '編集(E)...', '耐力設定(T)...', and '閉じる(X)' are on the right.

横架材端部金物一覧 (List of End of Transverse Member Joints): A window showing a list of joint types. The list includes: TH-10, TH-10D, TH-10H, TH-10U, TH-18, TH-18D, TH-24, TH-24D, TH-33, TH-33D, TH-45, TH-45D, TH-51, TH-51D, TH-57, TH-57D, TH-66, and TH-66D. Buttons for '編集(E)...' and '追加(A)...' are on the right.

横架材端部金物編集 (End of Transverse Member Joint Edit): A window for editing a specific joint type. The '耐力' (Strength) tab is selected. The '名称' (Name) field is set to 'TH-10'. A table shows the strength values for different conditions. A dropdown menu is open, showing options: 対梁 (Against Beam), 対柱 (Against Column), 対梁(両引) (Against Beam (Both Tension)), 対柱(片引) (Against Column (One Tension)), 対柱(両引) (Against Column (Both Tension)), and 指定無し (None Specified).

条件	長期せん断	短期せん断	短期弱軸	逆せん断	引張
対梁(片引)	4.18	7.6	0	6.9	10.3